

INSTRUCTIONS FOR INSTALLATION OF SINGLE OR DOUBLE CYLINDER DEADBOLTS AND THE REPLACEMENT OF EXISTING LOCKS

FOR USE ON DOOR THICK 1-3/8" TO 1-3/4" (35mm-45mm)

TOOLS REQUIRED FOR NEW CONSTRUCTION:

1 philips head screwdriver


1 2-1/8" (54mm) hole saw

1 1" (25mm) drill & 1 chisel

TOOLS REQUIRED FOR REPLACEMENT:

1 philips head screwdriver


1. MARK DOOR



- Fold and apply template on high edge of door bevel and mark center of door edge as indicated on template at the desired height from the floor.
- Mark center hole on door face through guide on template for either 2-3/8" or 2-3/4" (60mm or 70mm) backset.

NOTE: BACKSET ON DOOR FACE MUST BE SAME AS BACKSET OF YOUR LOCK.

2. DRILL HOLES




1" (25mm)
FOR DEADBOLT

2-1/8" (54mm) HOLE
FOR LOCKSET


Drill holes as marked.

NOTE:
DRILL 2-1/8" (54mm)
HOLE FROM BOTH
SIDES OF DOOR TO AVOID
SPLITTING WOOD.


3. INSTALL LATCH



Insert latch in hole.
Mark outline of
face plate and
remove latch.




Chisel 1/8" (3mm)
deep or until face
plate flush with
door edge.




Insert latch and
tighten screws.

4. INSTALL STRIKE




Close door to mark
horizontal center
line of strike.




Measure one half
of door thickness
from door stop and
mark vertical center
line of strike. Drill 1"
(25mm) hole 1" (25
mm) deep at inter-


screw holes on
strike with center
lines on jamb.
Mark outline and
chisel 5/64" (2mm)
deep for strike.




5. INSTALL SINGLE CYLINDER




- Retract deadbolt to unlock position.
- Insert exterior tail piece horizontally through latch crank.
- Press exterior cylinder flush against door.
- Install inside turn unit and tighten installation screws.



6. INSTALL DOUBLE CYLINDER



- Retract deadbolt to unlock position.
- Insert exterior tail piece horizontally through latch crank.
- Press exterior cylinder flush against door.
- Insert interior tail piece vertically through latch crank.
- Press interior cylinder flush against door and tighten installation screws.



INSTRUCTIONS FOR INSTALLATION OF SINGLE OR DOUBLE CYLINDER DEADBOLTS AND THE REPLACEMENT OF EXISTING LOCKS

FOR USE ON DOOR THICK 1-3/8" TO 1-3/4" (35mm-45mm)

TOOLS REQUIRED FOR NEW CONSTRUCTION:

1 philips head screwdriver


1 2-1/8" (54mm) hole saw

1 1" (25mm) drill & 1 chisel

TOOLS REQUIRED FOR REPLACEMENT:

1 philips head screwdriver


1. MARK DOOR



- Fold and apply template on high edge of door bevel and mark center of door edge as indicated on template at the desired height from the floor.
- Mark center hole on door face through guide on template for either 2-3/8" or 2-3/4" (60mm or 70mm) backset.

NOTE: BACKSET ON DOOR FACE MUST BE SAME AS BACKSET OF YOUR LOCK.

2. DRILL HOLES




1" (25mm)
FOR DEADBOLT

2-1/8" (54mm) HOLE
FOR LOCKSET

Drill holes as marked.

NOTE:
DRILL 2-1/8" (54mm)
HOLE FROM BOTH
SIDES OF DOOR TO AVOID
SPLITTING WOOD.


3. INSTALL LATCH



Insert latch in hole.
Mark outline of
face plate and
remove latch.




Chisel 1/8" (3mm)
deep or until face
plate flush with
door edge.




Insert latch and
tighten screws.

4. INSTALL STRIKE




Close door to mark
horizontal center
line of strike.




Measure one half
of door thickness
from door stop and
mark vertical center
line of strike. Drill 1"
(25mm) hole 1" (25
mm) deep at inter-


screw holes on
strike with center
lines on jamb.
Mark outline and
chisel 5/64" (2mm)
deep for strike.




5. INSTALL SINGLE CYLINDER



- Retract deadbolt to unlock position.
- Insert exterior tail piece horizontally through latch crank.
- Press exterior cylinder flush against door.
- Install inside turn unit and tighten installation screws.



6. INSTALL DOUBLE CYLINDER



- Retract deadbolt to unlock position.
- Insert exterior tail piece horizontally through latch crank.
- Press exterior cylinder flush against door.
- Insert interior tail piece vertically through latch crank.
- Press interior cylinder flush against door and tighten installation screws.

